

Meta Trak S7-ATS

Meta Trak S5-VTS V2

User Guide



Contents

Stolen Vehicle Procedure	3
System Features	3
Subscription Documentation	3
Alerts	4
Battery Disconnection	
Unauthorised Movement	
Low Vehicle Battery	
ID Tag Not Recognised (S5 only)	
ID Tag Battery Low (S5 only)	
Vehicle Alarm Trigger (Option)	
Immobiliser Operation	5
Automatic STARTER Immobilisation (Option S5 only)	
DEADLOCK Immobilisation (S5 only)	
Manual STARTER Immobilisation (Option)	
OBD Port Immobilisation (Option)	
Maintenance	6
Replacing the ID Tag battery	
System Health Check	
Warranty	
Change of details or Registered keeper	
Smartphone App / Web Access	
Contact Us	7
Secure Operating Centre (SOC):	
Customer Services:	

Stolen Vehicle Procedure

In the event of **discovering your vehicle stolen** you should:

- Call our Secure Operating Centre (SOC) on **+44(0)330 2200339**, the SOC will commence tracking the vehicle.
- **Contact the Police** to report the theft and obtain a Crime Reference Number (CRN).
- **Call the SOC immediately** to provide them with your CRN, the SOC will then liaise with the Police directly to locate your vehicle.

In the event of the SOC **receiving an AUTOMATIC ALERT** from your tracking system:

The SOC will attempt to contact you in order to confirm the vehicle status; the SOC will NOT contact the police until the theft has been confirmed with you.

You will also receive a push notification advising you that an alert has been sent to the SOC (provided you have the Meta Trak app running).

NOTE: For operational reasons the 'caller ID' of the inbound call from the SOC will be shown as 'UNKNOWN' or 'Private No.'

System Features

- Professional Stolen Vehicle Tracking
- Latest satellite location technology
- Journey Scoring
- Real-time tracking via app/web
- Smartphone App
- Web Portal
- 3yr Warranty
- European Coverage
- Insurance Approved
- ID-Tag Recognition (S5 only)
- STARTER Immobilisation (option)
- OBD Port Immobiliser (option)

Subscription Documentation

You will have received an email when your system was activated by your dealer.

This email provides you with:

1. Details of how to log-in to the web portal and smartphone app.
2. Links to download the smartphone app.
3. Your contract information to be used as proof of installation for your insurance company.

Please check all information is correct!

Alerts

A **push notification** will be sent to your smartphone (provided you have the Meta Trak app running).



Battery Disconnection

In the event of a **sabotage** of the vehicle power system or battery disconnection a theft alert will be sent immediately to our Secure Operating Centre (SOC). The SOC will attempt to contact you in order to verify the status of the vehicle.


Should you need to disconnect the vehicle battery for maintenance reasons you should first set the system to '**Garage Mode**'.



Unauthorised Movement

In the event of the vehicle being moved **without the ignition ON** a theft alert will be sent to our Secure Operating Centre (SOC). The SOC will attempt to contact you in order to verify the status of the vehicle.

Should you need to **transport** the vehicle or travel by ferry you should first set the system to '**Transport Mode**'.




Low Vehicle Battery

Is generated in the event of the vehicle battery becoming low (<11.5V).



ID Tag Not Recognised (S5 only)

The ID-Tag should be attached to the vehicle keys.



ID Tag



In the event of the **vehicle being driven WITHOUT** the ID Tag e.g. an unauthorised key, an alert will be sent to our SOC. The SOC will attempt to contact you in order to verify the status of the vehicle.

NOTE: The **push button** of the ID Tag is **NOT REQUIRED** to be used in normal operation.



ID Tag Battery Low (S5 only)

In the event of the ID Tag battery becoming low a **push notification** providing you all required information will be sent to your smartphone.



Vehicle Alarm Trigger (Option)

Is generated in the event of the vehicle alarm system being triggered.

Immobiliser Operation



Automatic STARTER Immobilisation (Option S5 only)

If your system has been installed with STARTER immobilisation the engine will be prevented from starting whenever the immobiliser is SET.

The Meta Trak STARTER immobilisation controls the operation of the starter motor only i.e. it cannot interrupt the running of the vehicle. Furthermore, the starter immobiliser cannot become SET before the ignition has been switched off for > 90secs.

SETTING OPERATION - The immobiliser will automatically become set 90 seconds after the ignition has been switched OFF and the ID-Tag has gone out of range.

UN-SETTING OPERATION - The immobiliser will automatically unset when the ID-Tag comes into range.



DEADLOCK Immobilisation (S5 only)

To **PREVENT** the engine from being started **EVEN with the ID-Tag present** send the following Command from the web or app: **“Immob BLOCK”**

To **ALLOW** the engine to be started send the following command from the web or app: **“Immob UNBLOCK”**.

The command may also be to unset when the ID-Tag is not available



Manual STARTER Immobilisation (Option)

If your system has been installed with STARTER immobilisation (**without the additional ID tag**) the STARTER immobiliser can be manually set via the smartphone app or web portal.

To **PREVENT** the engine from being started send the following Command from the web or app: **“Immobiliser BLOCK (B3)”**

To **ALLOW** the engine to be started send the following command from the web or app: **“Immobiliser UNBLOCK (B3)”**



OBD Port Immobilisation (Option)

If your system has been installed with an OBD Port Immobiliser the OBD (Diagnostic) Port will be disabled in order to prevent un-authorized use, thus preventing key programming.

The port should be ENABLED ONLY when the vehicle is with an authorised service agent in order to enable the use of diagnostic equipment.

To **PREVENT** access to the OBD Port send the following command from the web or app: **“Immobiliser BLOCK (B3)”**

To **ALLOW** access to the OBD port for an authorised service agent send the Command from the web or app: **“Immobiliser UNBLOCK (B3)”**

Maintenance

Replacing the ID Tag battery

Battery Type: CR2032

Carefully prise apart the upper and lower parts of the ID tag.

Slide out the battery observing the orientation.

Slide in the new battery in the same orientation.

Re-assemble the tag; normal operation should be resumed.

See our how-to video at:

<http://www.metatrak.co.uk/howto>

System Health Check

Your Meta Trak Tracking System is health checked every 28 days to ensure correct operation, as per insurance requirements. In the event of a fault being detected our customer services department will contact you to discuss further.

Warranty

Meta Trak hardware includes a 3-year parts warranty.

Change of details or Registered keeper

Please inform us as soon as possible of any changes to your contract information.

Such as:

- Changes to contact numbers
- Change of vehicle registration
- Change of email address
- Change of registered keeper

Smartphone App / Web Access

Please note that in the event of a theft alert being sent to the SOC your access to the smartphone app and your web portal will be temporarily suspended whilst the SOC manages the incident, normal operation will be restored immediately after the incident is closed by the SOC.



Contact Us

Secure Operating Centre (SOC):

+44(0)330 2200339

24hrs for theft or operational issues
only

Customer Services:

+44(0)203 332 0121

Mon-Fri 9am-5pm for general enquiries

www.metatrak.co.uk

Distributed in the UK and the Republic of Ireland
by:

Vestatec Distribution Limited

Unit 8, The Links

Popham Close

Hanworth

Middlesex TW13 6JE

