

Meta Trak Shield User Guide



Contents

System Features	3
Subscription Documentation	3
Alerts	3
Battery Disconnection	
Unauthorised Movement	
Low Vehicle Battery	
Driver ID Tag Not Recognised (Option)	
Driver ID Tag Battery Low	
Vehicle Alarm Trigger	
System Operation	5
Automatic STARTER Immobilisation (Option)	
Manual STARTER Immobilisation (Option)	
OBD Port Immobilisation (Option)	
Panic Facility (Option)	
Maintenance	7
Replacing the ID Tag battery	
Warranty	7
Change of details or Registered keeper	7
Contact Us	8

System Features

- Self-tracking/management solution
- Latest satellite location technology
- Journey Scoring
- Journey history
- Real-time tracking via app/web
- Smartphone App
- Web Portal
- 3yr Warranty
- European Coverage
- Driver Recognition (option)
- STARTER Immobilisation (option)
- OBD Port Immobiliser (option)

Meta Trak Shield is a self-managed tracking solution which IS NOT monitored by Meta Trak for theft.

Subscription Documentation


You will have received an email when your system was activated by your dealer.

This email provides you with:

1. Details of how to log-in to the web portal and smartphone app.
2. Links to download the smartphone app.
3. Your contract information.

Please check all information is correct!

Alerts



Battery Disconnection

In the event of battery disconnection, a **push notification** will be sent to your smartphone (provided you have the Meta Trak app running).

Should you need to disconnect the vehicle battery for maintenance reasons you should first set the system to **'Garage Mode'** via the app or web portal in order to avoid generating a false alert.

REMEMBER to set the system back to **'Normal Mode'** once the maintenance is completed.




Unauthorised Movement

(not available if installed in 2-wire mode)

In the event of a vehicle movement without the engine running a **push notification** will be sent to your smartphone (provided you have the Meta Trak app running).


Should you need to **transport** the vehicle or travel by ferry you should first set the system to **'Transport Mode'** via the app or web portal in order to avoid generating a false alert.

REMEMBER to set the system back to **'Normal Mode'** once the transportation is completed.



Low Vehicle Battery

In the event of the vehicle battery becoming low (<11.5V) a **push notification** will be sent to your smartphone (provided you have the Meta Trak app running).



Driver ID Tag Battery Low

In the event of the ID Tag battery becoming low a **push notification** providing you all required information will be sent to your smartphone (provided you have the Meta Trak app running). **Replace as soon as possible!**



Driver ID Tag Not Recognised (Option)

Where the optional Driver ID tag has been made available the tag should be either attached to the vehicle keys or present on the driver's person.



Vehicle Alarm Trigger

If applicable, in the event of the vehicle alarm system being triggered a **push notification** will be sent to your smartphone (provided you have the Meta Trak app running).



Fig. 1

In the event of the **vehicle being driven WITHOUT** the Driver ID Tag a **push notification** will be sent to your smartphone (provided you have the Meta Trak app running).

NOTE: the **push button** of the Driver ID Tag is **NOT REQUIRED** to be used in normal operation.

System Operation



Automatic STARTER Immobilisation (Option)

If your system has been installed with STARTER immobilisation (**with** the additional *Driver ID tag*) the engine will be prevented from starting whenever the immobiliser is SET.

The Meta Trak STARTER immobilisation controls the operation of the starter motor only i.e. it cannot interrupt the running of the vehicle. Furthermore, the starter immobiliser cannot become active before the ignition has been switched off for > 30secs.

SETTING OPERATION - The starter immobiliser will automatically become set 30 seconds after the ignition has been switched OFF.

UN-SETTING OPERATION - Upon switching the ignition ON your ID tag will be recognised by the system and the STARTER immobiliser will automatically un-set.



Manual STARTER Immobilisation (Option)

If your system has been installed with STARTER immobilisation (**without** the additional *Driver ID tag*) the STARTER immobiliser can be manually set via the smartphone app or web portal.

The Meta Trak STARTER immobilisation controls the operation of the starter motor only i.e. it cannot interrupt the running of the vehicle. Furthermore, the starter immobiliser cannot become active before the ignition has been switched off for >30secs.

To **PREVENT** the engine from being started send the following Command from the web or app: **“ARM Immobiliser”**

To **ALLOW** the engine to be started send the following command from the web or app: **“DISARM Immobiliser”**



OBD Port Immobilisation (Option)

If your system has been installed with an OBD Port Immobiliser the OBD/Diagnostic Port will be disabled in order to prevent un-authorized use.

The port should be ENABLED ONLY when the vehicle is with an authorised service agent.

To **PREVENT** access to the OBD Port send the following command from the web or app:
“ARM OBD Immobiliser”

To **ALLOW** access to the OBD port for an authorised service agent send the Command from the web or app:
“DISARM Immobiliser”



Panic Facility (Option)

If your system has been installed with the PANIC facility the Flashers/Headlights and Horn/Siren can be activated via the smartphone app or web portal.

To **ENABLE** Panic facility send the following command from the web or app:
“PANIC ON”

To **STOP** the Panic cycle send the Command from the web or app:
“PANIC OFF”

Maintenance

Replacing the ID Tag battery

Battery Type: CR2032

Carefully prise apart the upper and lower parts of the ID tag.

Slide out the battery observing the orientation.

Slide in the new battery in the same orientation.

Re-assemble the tag; normal operation should be resumed.

See our how-to video at:

<http://www.metatrak.co.uk/howto>

Warranty

Meta Trak hardware includes a 3-year parts warranty.

Change of details or Registered keeper

Please inform us as soon as possible of any changes to your contract information.

Such as:

- Changes to contact numbers
- Change of vehicle registration
- Change of email address
- Change of registered keeper

Contact Us

Customer Services:

+44(0)203 332 0121

Mon-Fri 9am-5pm for general enquiries

www.metatrak.co.uk

Distributed in the UK and the Republic of Ireland
by:

Vestatec Distribution Limited

Unit 8, The Links

Popham Close

Hanworth

Middlesex TW13 6JE

